

Cell Cloning by Serial Dilution in 96 Well Plates Protocol









John A. Ryan, Ph.D. Corning Incorporated Life Sciences 900 Chelmsford St Lowell, MA 01851

Introduction

This technique is widely used for clonal isolation of hybridomas and other cell lines that are not attachment dependent. However, it is also very useful for cloning attachment dependent cells when the cell plating efficiency is very low, unknown or unpredictable. This method is fast and easy; however, like most clonal isolation methods, there is no guarantee that the colonies arose from single cells. Recloning a second time is advised to increase the likelihood that the cells originated from a single cell.

Supplies

Nonsterile

- 1. Pipetting aids Corning Cat. No. 4910 (1)
- 2. Disposal tray or bucket for used pipettes (1)
- 3. Marking pen (1)
- 4. 200µL pipettor Corning Cat. No. 4963 (1)
- 5. 8-channel 200µL micropipettor- Corning Cat. No. 4888 (1)

Sterile


- 1. Cell culture medium (Appropriate culture medium for the cells that will be cloned) (30mL)
- 2. Cell suspension at 2x10⁴ cells/mL (200µL needed per microplate)
- 3. 96 well cell culture microplate Corning Cat. No. 3585 (1) This plate is designed for cloning cells that you want to attach to the well bottom; for cloning cells you want to stay in suspension use a 96 well round bottom **Ultra-Low Attachment** microplate Corning Cat. No. 7007.
- 4. Sterile pipettor tips Corning Cat. No. 4711 or 4810
- 5. Reagent dispensing reservoir/tray Corning Cat. No. 4870 or 4871 (1)
- 6. 1, 5, and 10mL pipettes Corning Cat. No. 4485, 4487 and 4488



Corning offers 8- and 12channel adjustable 200µL micropipettors that are ideal for working in 96 well plates.

Procedure

1. Fill the reagent dispensing tray with 12mL of the appropriate culture medium, then using an 8-channel micropipettor add 100μL medium to all the wells in the 96 well plate except well **Al** (see diagram below) which is left empty.



Adding 4000 cells in well A1 (2x10⁴ cells/mL) is a good starting cell concentration. Increase this concentration for more difficult to grow cell lines.

- 2. Add 200μL of the cell suspension to well **A1**. (See Figure 1.) Then using a single channel pipettor quickly transfer 100μL from the first well to well B1 and mix by gently pipetting. Avoid bubbles. Using the same tip, repeat these 1:2 dilutions down the entire column, discarding 100μL from **H1** so that it ends up with the same volume as the wells above it.
- 3. With the 8-channel micropipettor add an additional 100μL of medium to each well in column 1 (giving a final volume of cells and medium of 200μL/well). Then using the same pipettor quickly transfer 100μL from the wells in the first column (**Al** through **H1**) to those in the second column (**A2** through **H2**) and mix by gently pipetting. **Avoid bubbles**!
- 4. Using the same tips, repeat these 1:2 dilutions across the entire plate, discarding l00μL from each of the wells in the last column (A12 through H12) so that all the wells end up with 100μL of cell suspension.
- 5. Bring the final volume of all the wells to 200μL by adding 100μL medium to each well. Then label the plate with the date and cell type. Adding filtered conditioned medium (medium in which cells have been previously grown for 24 hours) to the wells can increase the success rate (cloning efficiency) for difficult to grow cells.
- 6. Incubate plate undisturbed at 37°C in a humidified CO₂ incubator.
- 7. Clones should be detectable by microscopy after 4 to 5 days and be ready to score after 7 to 10 days, depending on the growth rate of the cells. (See Figure 2 on page 3.) Check each well and mark all wells that contain just a single colony. These colonies can then be subcultured from the wells into

Transferring clones directly from a well in a 96 well plate into a T-25 flask is not recommended. The cells may be unable to grow due to their inability to condition the larger volume of medium in the flask. Using some conditioned medium when subculturing the cells for the first time will also help them survive and grow.

larger vessels. Usually each clone is transferred into a single well in a 12 well or 24 well plate.



Figure 2. Example of a fixed and stained (70% ethanol fixation followed by 1% crystal violet staining) plate containing a dilution plating of CHO-K1 cells. The highest cell densities occur in the wells immediately surrounding the A1 position. Wells A10, D10, E6, E11, F7, G6 and H4 appear to contain single colonies.

Acknowledgements

This protocol has evolved from a protocol I developed for cell culture training courses at the University of Connecticut, Storrs, Connecticut. I would like to thank all of my colleagues and students who, over the years, have contributed ideas and suggestions to its development.

For additional product or technical information, please visit our web site at www.corning.com/lifesciences or call at 1-800-492-1110. International customers can call at 978-635-2200.

CORNING

Corning Incorporated Life Sciences

Tower 2, 4th Floor 900 Chelmsford St. Lowell, MA 01851 t 800.492.1110 t 978.442.2200 f 978.442.2476

www.corning.com/

Worldwide Support Offices

ASIA/PACIFIC

Australia t 61 2-9416-04

t 61 2-9416-0492 f 61 2-9416-0493

China t 86 21-3222-4666 f 86 21-6288-1575

Hong Kong t 852-2807-2723 f 852-2807-2152 India

t 91 11 341 3440 f 91 11 341 1520

Japan

t 81 (0) 3-3586 1996/1997 f 81 (0) 3-3586 1291/1292

Korea

t 82 2-796-9500 f 82 2-796-9300

Singapore t 65 6733-6511 f 65 6735-2913

Taiwan

t 886 2-2716-0338 f 886 2-2716-0339

EUROPE

France t 0800 916 882 f 0800 918 636

Germany t 0800 101 1153 f 0800 101 2427

United Kingdom t 0800 376 8660 f 0800 279 1117

The Netherlands

t 31 (0) 20 659 60 51 f 31 (0) 20 659 76 73

All other European Countries

t 31(0) 20 659 60 51 f 31(0) 20 659 76 73

LATIN AMERICA Brasil

t (55-11) 3089-7400 f (55-11) 6845-2236

Mexico

t (52-81) 8313-8400 f (52-81) 8313-8589

Corning is a registered trademark of Corning Incorporated, Corning, New York.